

Routine Pelvis MRI

Reviewed By: Lawrence Tang, MD

Last Reviewed: May 2022

Contact: (866) 761-4200, Option 1

General parameters (1.5 T magnets):

For all T1 sequences, please keep TE below 20 (between 10 and 15 if possible); TR 500-600.

For all T2 FS sequences, use equivalent of FSE/TSE. TE of mid to upper 50's is the most ideal for Siemens, 60-65 for GE, and ~ 60 for Toshiba.

It is important to have TE long enough for T2 weighting but not so long that it is signal starved.

For STIR, TI = ~ 135

Comments: Whole pelvis - all pelvis cor and ax sequences need to cover from bone to bone to be adequate.

- cor T1
- cor STIR
- ax T1
- ax T2 FS